

Notes For TTL Modulation

For the TTL modulation laser, please note that there are two lines (red wire of “+” , blank wire of “-”) in the circuit panel for TTL signal (0-5VDC) input.

1. Without signal input (or the lines open), the laser is CW operation

Input <0.7V Laser No Output

2. With signal 0VDC input, the laser outputs Min value/No output.

Input >2.3V Laser Output

3. With signal 4.5VDC input, the laser outputs MAX value.

Do not input >5.2V